4x 100M SFP/SFP+ USB to RS232/RS485/422 Serial Adapter with overvoltage/over Peak-to-Peak Protection

Wide Temp Fan-less Operating Industrial Grade USB to Serial Converter

1. Product Introduction/Einführung

- USB auf RS232/RS485/RS422 Serielle Schnittstelle Adapter mit Überspannungs-/Überspannungsschutz
- Breites Temperaturbereich, lüfterloser Betrieb, Industrieller USB zu Serieller Konverter
- Der USB zu RS232/RS485/RS422 Serielle Schnittstelle Adapter mit Überspannungs-/Überspannungsschutz ist ein Hochleistungs-Industrie-Kommunikationsgerät, das USB-Schnittstelle in RS232/RS485/RS422 Serielle Schnittstelle umwandelt. Es verfügt über eine Überspannungs-/Überspannungsschutzfunktion, die Ihre Geräte vor Schäden durch Überspannungsspitzen schützt. Der Adapter unterstützt einen breiten Betriebstemperaturbereich und ist für den lüfterlosen Betrieb ausgelegt, was ihn ideal für industrielle Umgebungen macht. Mit seiner robusten Konstruktion und zuverlässigen Leistung bietet dieser Adapter eine nahtlose Verbindung für Ihre seriellen Geräte.

2. Specifications/Technische Daten

- Chipset: FTDI FT232RL
- Interface: USB 2.0 Full Speed
- Serial Signals: TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
- Serial Baud Rate: 300bps ~ 921.6Kbps
- Data Bits: 5, 6, 7, 8
- Stop Bits: 1, 1.5, 2
- Parity: None, Even, Odd, Mark, Space
- Flow Control: None, RTS/CTS, DTR/DSR, XON/XOFF
- Overvoltage Protection: 15KV ESD Protection
- Overvoltage Protection: Up to 400W Peak Pulse Power (8/20μs)
- Operating Temperature: -40°C ~ 85°C
- Storage Temperature: -40°C ~ 85°C
- Relative Humidity: 5% ~ 95% RH (Non-condensing)
- Dimensions: 100 x 70 x 22mm (3.94 x 2.76 x 0.87 inches)
- Weight: 150g (5.29 oz)

3. Installationsbeschreibung

Nr.	Beschreibung	Description
1	Treiber und Konfigurationsprogramm herunterladen	Download driver and configuration program
2	Treiber installieren	Install driver
3	Gerät anschließen	Connect device
4	Gerät prüfen	Check device
5	Konfigurieren	Configure

4. Installationsvorbereitung/Install

5. Treiberinstallation

6. Überprüfung

- Treiber Version
- Gerätemanager

7. Konfiguration

- Baudrate
- Datenbits
- Stoppbits
- Parität
- Flusskontrolle

8. Anleitung zur Treiberinstallation für serielle Schnittstellen

Laden Sie den Treiber für Ihr Betriebssystem herunter und installieren Sie ihn. Verbinden Sie das Gerät mit dem Computer und überprüfen Sie, ob es im Gerätemanager erkannt wird. Konfigurieren Sie die Einstellungen nach Bedarf.

Laden Sie den Treiber für Ihr Betriebssystem herunter und installieren Sie ihn. Verbinden Sie das Gerät mit dem Computer und überprüfen Sie, ob es im Gerätemanager erkannt wird. Konfigurieren Sie die Einstellungen nach Bedarf.

Laden Sie den Treiber für Ihr Betriebssystem herunter und installieren Sie ihn. Verbinden Sie das Gerät mit dem Computer und überprüfen Sie, ob es im Gerätemanager erkannt wird. Konfigurieren Sie die Einstellungen nach Bedarf.

Laden Sie den Treiber für Ihr Betriebssystem herunter und installieren Sie ihn. Verbinden Sie das Gerät mit dem Computer und überprüfen Sie, ob es im Gerätemanager erkannt wird. Konfigurieren Sie die Einstellungen nach Bedarf.

9. Treiberinstallation

Treiber herunterladen: Treiber herunterladen

https://www.ftdichip.com/Drivers/VCP.htm

Produktgarantiekarte

Kundeninformationen

Name des Kunden:	
Kontaktinformationen:	
Kaufdatum:	
Name des Händlers:	
Kontaktinformationen des Händlers:	

Produktinformationen und Garantieinformationen

Produktmodell:	Seriennummer:
Garantiezeitraum:	Garantiebeginn:
Garantieende:	

Garantiebedingungen:

1. Innerhalb des Garantiezeitraums, wenn das Produkt aufgrund von Qualitätsproblemen ausfällt, bietet der Händler kostenlose Reparatur- oder Ersatzdienste an.
2. Die Garantie gilt nicht für Schäden, die durch unsachgemäße Verwendung, Demontage, Reparatur oder Modifikation durch den Benutzer verursacht wurden.
3. Die Garantie gilt nicht für Schäden, die durch Naturkatastrophen, Unfälle oder andere Faktoren außerhalb der Kontrolle des Händlers verursacht wurden.
4. Bitte bewahren Sie diese Garantiekarte ordnungsgemäß auf und legen Sie sie bei Garantieansprüchen vor.

Hinweis: Diese Garantiekarte ist nur für Produkte innerhalb des Garantiezeitraums gültig. Bitte füllen Sie die Informationen vollständig und korrekt aus.

4x 100M SFP/SFP+ USB to RS232/RS485/RS422 Serial Adapter with overvoltage/over Peak-to-Peak Protection

Wide Temp Fan-less Operating Industrial Grade USB to Serial Converter

1. 概述

- USB 转 RS232/RS485/RS422 串口适配器，带过压/过压保护
- 宽温无风扇工业级 USB 转串口转换器
- USB 转 RS232/RS485/RS422 串口适配器，带过压/过压保护，是一款高性能工业通信设备，可将 USB 接口转换为 RS232/RS485/RS422 串口。它具有过压/过压保护功能，可保护您的设备免受电压峰值损坏。该适配器支持宽工作温度范围，设计为无风扇运行，非常适合工业环境。凭借其坚固的结构和可靠的性能，该适配器为您的串口设备提供无缝连接。

2. 规格

- 芯片组：FTDI FT232RL
- 接口：USB 2.0 全速
- 串口信号：TxD、RxD、RTS、CTS、DTR、DSR、DCD、RI、GND
- 串口波特率：300bps ~ 921.6Kbps
- 数据位：5、6、7、8
- 停止位：1、1.5、2
- 奇偶校验：无、偶、奇、标记、空格
- 流控制：无、RTS/CTS、DTR/DSR、XON/XOFF
- 过压保护：15KV ESD 保护
- 过压保护：最高 400W 峰值脉冲功率（8/20μs）
- 工作温度：-40°C ~ 85°C
- 存储温度：-40°C ~ 85°C
- 相对湿度：5% ~ 95% RH（无冷凝）
- 尺寸：100 x 70 x 22mm（3.94 x 2.76 x 0.87 英寸）
- 重量：150g（5.29 盎司）

3. 安装说明

编号	说明	Description
1	下载驱动和配置程序	Download driver and configuration program
2	安装驱动	Install driver
3	连接设备	Connect device
4	检查设备	Check device
5	配置	Configure

4. 安装准备/Install

5. 驱动安装

6. 验证

- 驱动版本
- 设备管理器

7. 配置

- 波特率
- 数据位
- 停止位
- 奇偶校验
- 流控制

8. 串口驱动安装指南

从官网下载适用于您操作系统的驱动程序并安装。将设备连接到计算机，并检查设备管理器中是否识别到该设备。根据需要配置设置。

从官网下载适用于您操作系统的驱动程序并安装。将设备连接到计算机，并检查设备管理器中是否识别到该设备。根据需要配置设置。

从官网下载适用于您操作系统的驱动程序并安装。将设备连接到计算机，并检查设备管理器中是否识别到该设备。根据需要配置设置。

从官网下载适用于您操作系统的驱动程序并安装。将设备连接到计算机，并检查设备管理器中是否识别到该设备。根据需要配置设置。

9. 驱动安装

驱动下载：驱动下载

https://www.ftdichip.com/Drivers/VCP.htm

保修卡

客户信息	
姓名：	
联系方式：	
购买日期：	
经销商：	
经销商联系方式：	
产品信息和保修信息	
产品型号：	序列号：
保修期：	保修开始日期：
保修结束：	

保修条款：

1. 在保修期内，如果产品因质量问题发生故障，经销商将提供免费维修或更换服务。
2. 保修不适用于因用户不当使用、拆卸、维修或修改而造成的损坏。
3. 保修不适用于因自然灾害、事故或经销商无法控制的其他因素而造成的损坏。
4. 请妥善保管此保修卡，并在保修索赔时出示。

注意：此保修卡仅适用于保修期内的产品。请填写完整准确的信息。

4x 100M SFP/SFP+ USB to RS232/RS485/RS422 Serial Adapter with overvoltage/over Peak-to-Peak Protection

Wide Temp Fan-less Operating Industrial Grade USB to Serial Converter

1. Product Introduction

- USB to RS232/RS485/RS422 Serial Adapter with overvoltage/over Peak-to-Peak Protection
- Wide Temp Fan-less Operating Industrial Grade USB to Serial Converter
- The USB to RS232/RS485/RS422 Serial Adapter with overvoltage/over Peak-to-Peak Protection is a high-performance industrial communication device that converts USB interface to RS232/RS485/RS422 serial interface. It features overvoltage/over Peak-to-Peak protection, which safeguards your devices from damage caused by voltage spikes. The adapter supports a wide operating temperature range and is designed for fan-less operation, making it ideal for industrial environments. With its robust construction and reliable performance, this adapter provides seamless connectivity for your serial devices.

2. Specifications

- Chipset: FTDI FT232RL
- Interface: USB 2.0 Full Speed
- Serial Signals: TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
- Serial Baud Rate: 300bps ~ 921.6Kbps
- Data Bits: 5, 6, 7, 8
- Stop Bits: 1, 1.5, 2
- Parity: None, Even, Odd, Mark, Space
- Flow Control: None, RTS/CTS, DTR/DSR, XON/XOFF
- Overvoltage Protection: 15KV ESD Protection
- Overvoltage Protection: Up to 400W Peak Pulse Power (8/20μs)
- Operating Temperature: -40°C ~ 85°C
- Storage Temperature: -40°C ~ 85°C
- Relative Humidity: 5% ~ 95% RH (Non-condensing)
- Dimensions: 100 x 70 x 22mm (3.94 x 2.76 x 0.87 inches)
- Weight: 150g (5.29 oz)

3. Installation Instructions

No.	Description	Beschreibung
1	Download driver and configuration program	Treiber und Konfigurationsprogramm herunterladen
2	Install driver	Treiber installieren
3	Connect device	Gerät anschließen
4	Check device	Gerät prüfen
5	Configure	Konfigurieren

4. Preparation/Install

5. Driver Installation

6. Verification

- Driver Version
- Device Manager

7. Configuration

- Baud Rate
- Data Bits
- Stop Bits
- Parity
- Flow Control

8. Serial Port Driver Installation Guide

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

9. Driver Installation Guide for FT Series Serial Cables

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

10. Driver Download

Driver Download: Download Driver

https://www.ftdichip.com/Drivers/VCP.htm

Product Warranty Card

Customer Information

Customer Name:	
Contact Information:	
Purchase Date:	
Dealer Name:	
Dealer Contact Information:	

Product Information and Warranty Information

Product Model:	Serial Number:
Warranty Period:	Warranty Start Date:
Warranty End Date:	

Warranty Terms:

1. During the warranty period, if the product malfunctions due to quality issues, the dealer will provide free repair or replacement services.
2. The warranty does not cover damages caused by improper use, disassembly, repair, or modification by the user.
3. The warranty does not cover damages caused by natural disasters, accidents, or other factors beyond the dealer's control.
4. Please keep this warranty card properly and present it when making a warranty claim.

Note: This warranty card is only valid for products within the warranty period. Please fill in the information completely and accurately.

4x 100M SFP/SFP+ USB to RS232/RS485/RS422 Serial Adapter with overvoltage/over Peak-to-Peak Protection

Wide Temp Fan-less Operating Industrial Grade USB to Serial Converter

1. Product Introduction

- USB to RS232/RS485/RS422 Serial Adapter with overvoltage/over Peak-to-Peak Protection
- Wide Temp Fan-less Operating Industrial Grade USB to Serial Converter
- The USB to RS232/RS485/RS422 Serial Adapter with overvoltage/over Peak-to-Peak Protection is a high-performance industrial communication device that converts USB interface to RS232/RS485/RS422 serial interface. It features overvoltage/over Peak-to-Peak protection, which safeguards your devices from damage caused by voltage spikes. The adapter supports a wide operating temperature range and is designed for fan-less operation, making it ideal for industrial environments. With its robust construction and reliable performance, this adapter provides seamless connectivity for your serial devices.

2. Technical Specifications

- Chipset: FTDI FT232RL
- Interface: USB 2.0 Full Speed
- Serial Signals: TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
- Serial Baud Rate: 300bps ~ 921.6Kbps
- Data Bits: 5, 6, 7, 8
- Stop Bits: 1, 1.5, 2
- Parity: None, Even, Odd, Mark, Space
- Flow Control: None, RTS/CTS, DTR/DSR, XON/XOFF
- Overvoltage Protection: 15KV ESD Protection
- Overvoltage Protection: Up to 400W Peak Pulse Power (8/20μs)
- Operating Temperature: -40°C ~ 85°C
- Storage Temperature: -40°C ~ 85°C
- Relative Humidity: 5% ~ 95% RH (Non-condensing)
- Dimensions: 100 x 70 x 22mm (3.94 x 2.76 x 0.87 inches)
- Weight: 150g (5.29 oz)

3. Installation Instructions

No.	Description	Beschreibung
1	Download driver and configuration program	Treiber und Konfigurationsprogramm herunterladen
2	Install driver	Treiber installieren
3	Connect device	Gerät anschließen
4	Check device	Gerät prüfen
5	Configure	Konfigurieren

4. Preparation/Install

5. Driver Installation

6. Verification

- Driver Version
- Device Manager

7. Configuration

- Baud Rate
- Data Bits
- Stop Bits
- Parity
- Flow Control

8. Serial Port Driver Installation Guide

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

Download the driver for your operating system from the official website and install it. Connect the device to the computer and check if it is recognized in the Device Manager. Configure the settings as needed.

9. Driver Download

Driver Download: Download Driver

https://www.ftdichip.com/Drivers/VCP.htm